

CATEGORY NO.

001

DESCRIPTION

PANELS FOR INDIAN RAILWAY

DESCRIPTION

CAT No.

Automatic Supply Changeover 32A CLS Panel for 5kVA AT as per latest RDSO specification No.: TI/SPC/PCI/ CLS/0020 with A & C Slip No.1, 2, 3 & 4 with latest amendments.

001-01-00032-004-01

Automatic Supply Changeover 63A CLS Panel for 10kVA AT as per latest RDSO specification No.: TI/SPC/PCI/ CLS/0020 with A & C Slip No.1, 2, 3 & 4 with latest amendments.

001-01-00063-004-01

Junction Box for 63A CLS suitable for 2 x 70 Sqmm Cable with Aluminium Bus Bar for Single Phase with Neutral.

001-01-00063-0JB-01

Automatic Supply Changeover 150A CLS Panel for 25kVA AT as per latest RDSO specification No.: TI/SPC/PCI/CLS/0020 with A & C Slip No.1, 2, 3 & 4 with latest amendments.

001-01-00150-004-01

Junction Box for 150A CLS Panel suitable for 185 Sqmm Cable with Aluminium Bus Bar for Single Phase with Neutral.

001-01-00150-0JB-01

Junction Box for termination of 150A CLS Panel suitable for 4Cx185 Sqmm Cable with Aluminium Bus Bar.

001-01-00150-0JB-02

240V LT Distribution Board for 10 kVA supply Transformer as per latest RDSO Specification No.: ETI/PSI/29(12/79) Rev. 1 Feb-93.	001-01-00240-000-01
110V DC Distribution Board as per latest RDSO Specification No.: ETI/PSI/29 (12/79) Rev-I (Feb'93).	001-01-00110-000-01
110V DC Iron Clad 2 Way Fuse Box with 2 Fuses Carriers & Bases.	001-01-00110-DC2-01
240V AC Iron Clad 4 Way Fuse Box with 4 Fuses Carriers & Bases.	001-01-00240-AC4-01
Terminal Board in Control Cubical as per RDSO Typ. Drawing No.: ETI/PSI/501.	001-01-00000-0TB-01
5 kVA AT Mast Distribution Box comprising of 2 No. HRC Fuse with Base, 1 No. Neutral Link and Heavy Duty Incoming & Outgoing Terminals.	001-02-05KVA-HMDB-01
10 kVA AT Mast Distribution Box comprising of 2 No. HRC Fuse with Base, 1 No. Neutral Link and Heavy Duty Incoming & Outgoing Terminals.	001-02-10KVA-HMDB-01
25 kVA AT Mast Distribution Box comprising of 1 No. Fuse Switch Unit with 2 No. HRC Fuse and Heavy Duty Incoming & Outgoing Terminals.	001-02-25KVA-HMDB-01

Point Junction Box	001-02-000PT-0JB-01
230V AC, 20A Goomty Automatic Changeover Panel	001-01-230AC-20A-01
110V AC, 20A Goomty Automatic Changeover Panel	001-01-110AC-20A-01
110V DC, 20A Goomty Automatic Changeover Panel	001-01-110DC-20A-01
24V DC, 20A Goomty Automatic Changeover Panel	001-01-024DC-20A-01
HT Panel 11KV (CEE Approved)	001-03-011KV-000-01
HT Panel 33KV (CEE Approved)	001-03-033KV-000-01
LT Panel / LT Control Panel 415V, 50Hz, 3 Phase (CEE Approved)	001-03-0415V-000-01
LT Switch Board 415V, 50Hz, 3 Phase (CEE Approved)	001-03-0415V-000-02

LT Feeder Pillar  
415V, 50Hz, 3 Phase (CEE Approved)

001-03-0415V-000-03

Power Distribution Board  
415V, 50Hz, 3 Phase (CEE Approved)

001-03-0415V-000-04

Automatic Capacitor Panel  
(CEE Approved)

001-03-0415V-000-05

Junction Box  
415V, 50Hz, 3 Phase (CEE Approved)

001-03-0415V-000-06

NOT IN THE LIST ABOVE

001-00-0000-000-00